

# VertX CS™

# “How to Order”

# Guide

To check status on your order, go to:  
*[www.hidcorp.com/order](http://www.hidcorp.com/order)*  
to register.

This document is subject to change without notice

## HID Corporation

### VertX CS™ Central Station Controller Part Numbers and Options

VertX CS Controller Description	Base Part	Rev. No.*	Use	Hardware Configuration	Config. Option	Memory Module <sup>2</sup>	Custom <sup>1</sup>
VertX CS V1000 64 Door Controller	71000	A	C = Central Station	P0 = PCB Assembly (plastic enclosure back plate & cover)	N	0 = 8 MB 1 = 16 MB 2 = 32 MB	XXXXXX
VertX CS V2000 2 Door Controller	72000	A	C = Central Station	P0 = PCB Assembly (plastic enclosure back plate & cover)	N	0 = 8 MB 1 = 16 MB 2 = 32 MB	XXXXXX

### VertX CS Central Station Controller Memory Upgrade Part Numbers

VertX CS Memory Upgrade	Base Part No.	Current Rev. No.*	Options
VertX CS Memory Upgrade, 16 MB	70016	A	N = None
VertX CS Memory Upgrade, 32 MB	70032	A	N = None

### VertX CS Central Station Panel Part Numbers and Options

VertX Panel Description	Base Part	Rev. No.*	Use	Hardware Configuration	Config. Option	Custom <sup>1</sup>
VertX CS V100 Reader/Door Interface	70100	A	C = Central Station	P0 = PCB Assembly (plastic enclosure back plate & cover)	N	XXXXXX
VertX CS V200 Input Monitor Interface	70200	A	C = Central Station	P0 = PCB Assembly (plastic enclosure back plate & cover)	N	XXXXXX
VertX CS V300 Output Control Interface	70300	A	C = Central Station	P0 = PCB Assembly (plastic enclosure back plate & cover)	N	XXXXXX

**For Technical Support, please call 303-453-4046 or 800-237-7769 (Press option 3).**

\*Revision numbers and availability are subject to change without notice.

<sup>1</sup> Consult Factory.

<sup>2</sup> Standard 8 MB onboard Memory included. Additional memory at extra charge.

**VertX CS Controller part # example: 71000ACP0N2**

**VertX CS Panel part # example: 70200ACP0N**